

# Assembly Instructions

## to the table System TA-4

**! ATTENTION!**  
Please do not pull out the table leg before connecting the tubing to the Pump. Air could be sucked into the hydraulic System.

- A. The rubber foots are mounted on the lower end of the table leg.
- B. The short joining beams TA 550 are mounted between 2 table legs with 4 screws M6x10 on each side. Please take care, that the gap to mount the screws shows in the rubber foot direction.
- C. Mount the long joining beam TA at the short beams. It can be placed in three depth positions. It is fixed on each side with 2 Washers and 2 Screws M8x20.
- D. Mount the table plate on the table plate supports
- E. Mount the drive Unit (Pump with Crank or Motor) on the table plate.
- F. The tubing has been laid to the pump. Please check also the added Assembly instruction "Connecting the hydraulic tubing".

### Delivery range

